



SL.	PART NO.	DESCRIPTION	QTY.
1	357000	Back Head Assy. (Sr.#1,2,3,4,5,6,7,8,9)	1
2	341013	Grip-Handle	2
3	354007	Back Head, Bare	1
4	354000	Throttle Lever	1
5	311017	T.L.Pin	2
6	354011	Oil Plug	1
7	354009	Oil Reg. Plug	1
8	351015	B.H.Nut	4
9	351017	Spring Washer	4
10	348005	Throttle Valve Assy.(Sr.#11,12,13)	1
11	351025	Retainer Ring	1
12	351023	O-Ring	1
13	351021	Throttle Valve	1
14	315071	T.V. Spring	1
15	351011	Seal - Cylinder	1
16	353002	Spring	1
17	358001	Valve Case Assy. (Sr.#19,19,20,21)	1
18	352009	"O" Ring-Valve Case	1
19	352005	Valve Case	1
20	352003	Distributor Valve	1
21	352001	Valve Case Lid	1
22	357003	O-Ring	1
23	357001	Air Inlet Swivel	1
24	357009	O-Ring	1
25	357005	Swivel Pipe	1
26	351009	Back Head Bolt	4
27	355003	Front Head Bolt	2
28	351005	Cylinder	1
29	351001	Piston	1
30	351003	Anvil Block Bush	1
31	351007	Anvil Block	1
32	357080	Front Head 1-1/8" (A) ( Sr.#32,33, 34, 35,36,37,38,39,40,42,43)	0
32	357050	Front Head 1-1/4" (B) (Sr.#32,33,34, 35,36,37,38,39,40,42,43)	1
33	358005	Front Head 1 1/8" (A)	0

SL.	PART NO.	DESCRIPTION	QTY.
33	358003	Front Head 1 1/4" (B)	1
34	356003	Latch	1
35	356001	Bushing Latch	1
36	355019	Nyloc Nut	1
37	355001	Plunger	1
38	355017	Spring-Plunger	1
39	355009	Taper Bush	2
40	355015	Latch Bolt	1
41	355005	Buffer Spring	2
42	314059	F.H. Nut	2
43	355013	Nut Lock	2
44	359006	Muffler Complete	0
45	359001	Dust Cap For Swivel Pipe	1
46	359003	Exhaust Dust Plug 1-1/4	1
47	359005	Exhaust Dust Plug 1-1/8	0