



SL	PART NO.	DESCRIPTION	QTY
1	349000	Back Head Assy.	1
2	351013	Grip	2
3	341003	Back Head	1
4	354000	Lever-Throttle	1
5	311017	T.L.Lever	2
6	354011	Oil Plug	1
7	354009	Oil Reg.Plug	1
8	341065	B.H.Nut	4
9	341087	Spring Washer	4
10	348005	Throttle .Valve Assy.	1
11	351025	Retainer Ring	1
12	351023	"O" Ring	1
13	351021	Throttle Valve	1
14	315071	T.V.Spring	1
15	351011	Seal-Cylinder	1
16	341011	Slack Ring	1
17	348007	Valve Case Assy	1
18	341018	Valve Case	1
19	341016	"O"Ring	1
20	341015	Valve	1
21	341019	V.C.Lid	1
22	357001	A.S. Nut	1
23	357003	"O" Ring	1
24	357009	"O" Ring	1
25	357005	Air Inlet Swivel	1
26	341069	B.H.Bolt	4
27	341071	F.H.Bolt	2
28	341001	Cylinder	1
29	341021	Piston	1
30	341025	A B Bush	1
31	314051	Anvil Block	1
32	348003	Front Head Assy. 1-1/8" (A)	1
32	344001	Front Head Assy. 1-1/4" (B)	0
33	342001	Hex Bush 1-1/4" (B)	0

SL	PART NO.	DESCRIPTION	QTY
33	342003	Hex Bush 1-1/8" (A)	1
34	341027	Front Head	1
35	348009	Latch Assy.	1
36	341055	Latch	1
37	341057	Bushing	1
38	355019	Nut	1
39	341053	Plunger	1
40	341051	Spring	1
41	355009	Taper Bush	2
42	355015	Latch Bolt	1
43	344055	Buffer Spring	2
44	341075	Nut Lock	2
45	341077	F.H.Nut	2
46	349998	Muffler	0