



RED INDICATES WEAR PARTS SHOULD ALWAYS KEPT IN STOCK

SL	PART NO.	DESCRIPTION	QTY
1	MD 3161 0230	Cover	1
2	MD 3161 0993	Lock Spring	1
3	MD 3161 0215	Stop Ring	1
4	MD 3161 0216	Rotation Chuck	1
5	MD 3161 0231	Front Head	1
6	MD 3161 0328	Rotation Chuck	1
7	MD 3161 0218	Rotation Chuck Bushing	1
8	MD 3161 0329	Guide Nut	1
9	MD 3141 0072	Nut	
10	MD 3141 0071	Nut	
11	MD 3161 0819	Intermediate Part	1
12	MD 3161 0235	Bushing	1
13	MD 3161 0307	Piston	1
14	MD 3161 0307 80	Piston Compl	1
15	MD 3161 0308	Rifle Nut	1
16	MD 291 1114	Nut	1
17	MD 3115 0122	Exhaust Guard	2
18	MD 3161 0524 80	Cylinder Complete	1
19	MD 3161 0468	Stud	2
20	MD 3141 0087 80	Cover	1
21	MD 3141 0088	Guide Pin	1
22	MD 3161 0333	Main Valve	1
23	MD 3141 0090	Rifle Bar Bearing	1
24	MD 3161 0369	Rifle Bar	1
25	MD 3161 0370	Pawl	8
26	MD 3141 0083	Pawl Pin	8
27	MD 3115 0774	Pawl Spring	8
28	MD 3161 0525	Damper	8
29	MD 3161 0377	Ratcht Box	1
30	MD 3161 0378	Pawl Lifting Ring	1
31	MD 9000 0335	Coupling Nut	1
32	MD 9000 0177	Hose Nipple	1
33	MD 9000 0485	Adopter	1
34	MD 3000 9922	Adopter	1

SL	PART NO.	DESCRIPTION	QTY
35	MD 663 2132	"O" Ring	2
36	MD 3141 0093	Back Head	1
37	MD 3161 0820	Pressure Screw	2
38	MD 3161 0229	Banjo Connection	2
39	MD 3161 0069	Plug	1
40	MD 3141 0095	Operating Piston	1
41	MD 3141 0096	Spring Guide	2
42	MD 3141 0097	Pressure Spring	2
43	MD 3141 0098	Plug	2
44	MD 3121 0477	Gasket	1
45	MD 3141 0070	Side Bolt	2
46	MD 3141 0224	Nut	2
47	3161 0376	Water Flushing Tube	1
48	MD 3161 0821	Adopter	1
49	MD 663 2124	'O' Ring	1
50	MD 3161 0822	Hose Nipple	1
51	MD 3161 0823	Coupling Nut	1